

BackBoxx Popp™ Installation

WARNING! Incorrect installation may result in product failure. Professional Partners is not responsible for installation.

1. Place BackBoxx™ Popp™ vertically into 16-inch-on-center wall cavity, or horizontally into 24-inch-on-center ceiling joists. (Also see Special Instructions on reverse)
2. Attach BackBoxx™ Popp™ to outward facing edges of studs using staple gun.
3. (Optional) Attach speaker or component bracket to studs directly in front of BackBoxx™ Popp™.
4. Using an awl, from the back side of the BackBoxx™ Popp™, open one Wire Dimple Locator in either end of BackBoxx™ Popp™.
5. Run wire through Wire Dimple Locator in BackBoxx™ Popp™ and leave a wire lead.
6. Seal opening around wire and Wire Dimple Locator with sealant.
7. Wall vapor barrier film should be attached to BackBoxx™ Popp™ flanges using approved sealing tape.
8. When installing speaker, allow the speaker magnet to contact, and push on, the dome inside the BackBoxx™ Popp™.

Special Installation Instructions

To install BackBoxx™ Popp™ in joists more closely spaced than 24", cut straight down one end of the BackBoxx™ Popp™, outside the dome area, from one flange to the opposite flange. Overlap the two pieces of the BackBoxx™ Popp™, and seal the overlapping seam using approved sealing tape and continue installation at step #3.