

How to Program your Smart Tags to your RFID Sensor Box

(LSG0 11.19.19)

1. If you haven't already, program Pet Mode for a set "pet width." This can be done by flipping dip switch 3 on and off. When the door opens and reaches the desired position, brace the door in place until it changes direction. The door does not need to be braced again.

2. Unscrew the silver screw at the top of the Sensor Box and remove the casing. Plug the RFID Sensor Box into the **Pet Sensor port** (second port from the bottom) on the unit motherboard using the provided cables.

(The box can be plugged in from the back or the bottom of the box, but to use the bottom port you must cut a hole in the RFID casing to allow the cable to go through)



3. To program your tags, use a small object to hold down the inset gold button inside the Sensor Box (accessible through the hole on the front surface). The LED light will change to purple - you can now immediately press all tags you wish to program.

4a. To program your **Smart Tags**, press the button on each Smart Tag you want to program.

4b. To program your **K9 Tags**, use a small object to press the button inside each K9 Tag you want to program.

4c. To program **both Smart Tags and K9 Tags**, press the button on each Smart Tag you want to program and use a small object to press the button inside each K9 Tag you want to program.

5. Once you've programmed the tags, test them individually to ensure all have been programmed by approaching the sensor box with tag in hand. The sensor box should flash red, and the door should open to the set Pet Width.

(PLEASE NOTE: Each RFID Sensor Box will take a maximum of four tags at once. RFID Sensor Boxes purchased prior to early 2019 can only take up to three tags reliably.)

6. If you're experiencing issues pairing a tag, try resetting the sensor box. Hold down the small gold button in the sensor box for a few seconds until the sensor box light turns purple. Release the button for one second, then hold it down again for 8 seconds, until the sensor box light turns blue. Then try to pair all tags you wish to use again.

- **In addition to contacting us if you have an issue, available for your reference is our video "AutoSlide: Programming your RFID/Smart Tag Set" which can be found on our YouTube channel "Autoslide USA Tech Help"**
- **Each tag takes 1x CR2032 battery (battery life depends on usage). Available for reference is our video "AutoSlide: How to Change your Smart Tag Battery" on our YouTube channel "Autoslide USA Tech Help" (a 1/16" screwdriver is recommended)**
- **When programming the RFID Sensor Box or K9 tags, a small object (such as a screwdriver or pin) is needed to hold down the small inset button.**
- **To program the distance, press and hold down the tag's button. To program the tag to 3 ft, release after one flash from the tag; for 6 ft, release after two flashes from the tag; for 10 ft, release after three flashes from the tag.**
- **To add or remove a tag, go through the programming process and click ALL the tags you wish to program during the programming process. Note that the system can still only reliably handle up to three tags.**

