


#### INSTALLATION INSTRUCTIONS

- 1. Snap adhesive back PCB supports into PCB as shown.
- 2. Peel backing from adhesive back PCB supports, place PCB in desired position and press firmly.

## **INSTALLATION OF STI-34188 8-ZONE RELAY BOARD**

All specifications and information shown were current as of publication and are subject to change without notice.





### **CABLE INSTALLATION TO RECEIVER**

- 1. Remove circuit board from base by removing circuit board mounting screw.
- 2. Drill 5/32 in. diameter hole in base as shown (circuit board must be removed.)
- 3. After drilling, cut out area as shown using side cutters or knife.
- 4. Route cable as shown and connect cable to jack on circuit board.
- 5. While replacing circuit board, gently pull cable from bottom of base to take up any slack in cable occurred during installation.

#### **SPECIFICATIONS**

- Standby: 12 VDC; 0.01mA
- Max Operating: 12 VDC; 164mA
- Form "C" Contact Rating (resistive): 120 VAC, 3A; 28 VDC, 3A

#### WARRANTY

One year warranty on electro mechanical and electronic components. Electronic warranty form at www.sti-usa.com/wc14.

# **INSTALLATION OF STI-34188 8-ZONE RELAY BOARD**

All specifications and information shown were current as of publication and are subject to change without notice.